



Seat_1 pc



Back rest_1 pc




Legs_2 pcs



Bottom cross bar -1pc




HARDWARE LIST

| No | Description | Q'ty |
|----|-----------------------------|-------|
| A | Hexagon head screw M6x100 | 8 pcs |
| B | Hexagon head screw M6x40 | 2 pcs |
| C | Seat cushion + Back cushion | 2 pc |
| D | Allen key | 1 pc |




BEFORE YOU START

1. Choose a clean, level, spacious assembly area. Avoid hard surfaces that may damage the product.
2. Check and ensure that you have all required contents for complete assembly.
3. Always read the assembly instructions carefully before beginning assembly.
4. The packaging and contents can be a choking hazard, therefore keep out of reach of small children at all times.
5. Do not over tighten the bolts as this may damage the thread.




Step 1: Using the 40mm hexagon head screw (B) attach the seat to the backrest with the allen key (D) as shown in the diagram
Step 2: Using the 100mm hexagon head screw (A) attach the armrests to the back and the seat. Carefully tighten all bolts.


FOR ASSISTANCE TO ASSEMBLE OR MISSING PARTS. PLEASE CONTACT AMART IMPORTS CUSTOMER SERVICE. FREE CALL: 1 800 009 466




Seat_1 pc



Back rest_1 pc




Legs_2 pcs



Bottom cross bar -1pc




HARDWARE LIST

| No | Description | Q'ty |
|----|-----------------------------|-------|
| A | Hexagon head screw M6x100 | 8 pcs |
| B | Hexagon head screw M6x40 | 2 pcs |
| C | Seat cushion + Back cushion | 2 pc |
| D | Allen key | 1 pc |




BEFORE YOU START

1. Choose a clean, level, spacious assembly area. Avoid hard surfaces that may damage the product.
2. Check and ensure that you have all required contents for complete assembly.
3. Always read the assembly instructions carefully before beginning assembly.
4. The packaging and contents can be a choking hazard, therefore keep out of reach of small children at all times.
5. Do not over tighten the bolts as this may damage the thread.




Step 1: Using the 40mm hexagon head screw (B) attach the seat to the backrest with the allen key (D) as shown in the diagram
Step 2: Using the 100mm hexagon head screw (A) attach the armrests to the back and the seat. Carefully tighten all bolts.


FOR ASSISTANCE TO ASSEMBLE OR MISSING PARTS. PLEASE CONTACT AMART IMPORTS CUSTOMER SERVICE. FREE CALL: 1 800 009 466




Seat_1 pc



Back rest_1 pc





Legs_2 pcs



Bottom cross bar -1pc


HARDWARE LIST

| No | Description | Q'ty |
|----|--------------------------------|-------|
| A | Hexagon head screw M6x100 | 8 pcs |
| B | Hexagon head screw M6x40 | 2 pcs |
| C | Seat cushion + Back cushion | 2 pc |
| D | Allen key | 1 pc |



BEFORE YOU START

1. Choose a clean, level, spacious assembly area. Avoid hard surfaces that may damage the product.
2. Check and ensure that you have all required contents for complete assembly.
3. Always read the assembly instructions carefully before beginning assembly.
4. The packaging and contents can be a choking hazard, therefore keep out of reach of small children at all times.
5. Do not over tighten the bolts as this may damage the thread.



Step 1: Using the 40mm hexagon head screw (B) attach the seat to the backrest with the allen key (D) as shown in the diagram
Step 2: Using the 100mm hexagon head screw (A) attach the armrests to the back and the seat. Carefully tighten all bolts.

FOR ASSISTANCE TO ASSEMBLE OR MISSING PARTS. PLEASE CONTACT AMART IMPORTS CUSTOMER SERVICE. FREE CALL: 1 800 009 466

